

70.00 mm

150.00 mm

350.00 mm

5 Projector connection

6 Wireless projection

IOS DEVICES
AirScreen: This feature allows the projector to be displayed on the same screen as the iPhone/iPad.

Note: Make sure the projector and mobile phone are connected to the same WIFI network (or the same hotspot).

The procedure is as follows:
Step 1: The projector goes to Applications and opens AirScreen
Step 2: Open the iPhone/iPad console interface and tap Airplay
Step 3: Select the device you want to share the screen

The name of the projection device can be defined in the projection APP, which is subject to the machine; It is recommended to connect to 5G WIFI to avoid stuttering on the same screen;

Android devices
Miracast: This feature allows the projector to be displayed on the same screen as an Android phone/tablet.

The procedure is as follows:
Step 1: Enter the projector and turn on Miracast;
Step 2: On your mobile phone, open the WIFI port, enter Settings > connect and share > screen projection;
Step 3: Select the device you want to share the screen.
During the connection process, a connection invitation may appear on the projector, click Accept

Different mobile phones have different Miracast setting paths and names, common names are: Media Output/Cast screen/multi-screen interaction, etc., please refer to the mobile phone for details.
Note: Due to the large number of mobile phone types, it is not guaranteed that all mobile phone models can be compatible with the same screen

7 Maintenance of the projector

The smart projector is a high-tech product integrating precision optics, electronics and machinery. If not regularly maintained, projector performance, effectiveness, and lifespan could be affected. The importance of regular and proper maintenance is as follows:

- Dustproof:** Excessive dust on the projector may affect heat dissipation. Clean the dust filter every one and a half months.
- Ventilation:** As the light source generates heat, ensure that airflow through the projector air vents are not obstructed. Reduced air flow will affect projector performance and lifespan.
- Lens Maintenance:** Lens performance is core to projector performance as poor maintenance affects image quality. Regularly use a soft cotton cloth to clean the lens surface, do not use a hard cloth or something corrosive. Wipe the lens.
- Cleaning:** Clean regularly with a cotton cloth to avoid dust build-up as it may affect heat dissipation.
- Moisture-proof:** Ensure that the humidity is between 45% - 60%. A higher air humidity may affect performance.
- Shockproof:** Ensure that the projector is not exposed to impacts, vibration, or shocks whether during operation, storage, or in transit.
- Do not install the projector on an unstable, shaky or uneven table.
- Do not place containers with liquid on top of the projector.

8 Warranty Card

WARRANTY CERTIFICATE

The manufacturer warrants this product to be free from defects in material and manufacturer's workmanship for a period of 1 year from the date of purchase. This warranty is subject to proper installation and usage as it is intended to be and as mentioned on the Egate's website. The manufacturer shall not be held responsible for any damage to the unit, kindly visit our website www.egate-world.com to locate your nearest service center.

Name: _____
Purchase Date: _____ Invoice No.: _____ Tel.: _____
S.N.O.: _____ Model: _____

Scan to Register
This Certificate is valid only after mandatory warranty registration within 15 days of purchase

For Support: call at 706 517 9993 / 4 / 5 or mail at support@egate-world.com

*For warranty policy please visit company website www.egate-world.com back. Any matter of legal dispute will be entertained in the jurisdiction of Madras court only.

1 Important Notes

How to use the device correctly:

- To avoid eye damage, do not point the lens towards the eyes when the light source is on.
- To avoid damage and overheating of the electronics, do not block the air inlet/outlet or vents.
- To avoid damaging the lens, do not use paper, cloth, or cleaning tools to wipe the lens. Use a blower to remove any dust particles.
- Keep the projector, parts, and accessories out of reach of children.
- Ensure that the projector is used in a dry and well-ventilated environment. The allowable operating temperature range is from 0°C to 35°C
- Do not store the projector in hot, cold, humid, or damp locations.
- Do not place any pressure on the projector or any shielding above or behind the projector.
- Do not expose the projector to any shock, vibration, impact, liquid droplets or splashes.
- Disassembling or attempting to repair the projector will invalidate the warranty. Contact an authorised repair service centre.
- Do not place any object on the projector.

2 Get to know the projector

Note: The appearance of the product is subject to the actual product. This picture is for reference only.

- Manual focusing
- On/off button
- HDMI input
- Headphone output
- USB input
- Power input (110-240V~)

3 Remote control

Power, Menu, Navigation Buttons, VOL-, All-round menu button (Only suitable for Android projector), Source, Mute, VOL+, Back, Mouse button

4 Device on/off

Step 1: Remove the projector from the packing box, then remove the packing bag and lens cover. Place the projector on a level table, then plug in the supplied power cord. Connect AC power and switch on - the indicator light on power button should be in red standby mode.

Step 2: Press the on-off button "⏻" on the body or the on-off button "⏻" on the remote control to start the projector. At this time, the indicator light on the projector panel turns solid blue and the lens emits light, and the projector is started.

Four-point trapezoid
Auto Keystone: The projector turns on Auto Keystone Correction (Vertical Keystone) by default

Manually adjust the four-point trapezoid: Open Settings, select Projection Setting, turn off Auto Trapezoid, and select Corner Correction

Image focus
Place the projector lens perpendicular to the projection screen or curtain wall, and adjust the lens focus wheel to clear the image. During the focus adjustment process, you can play a program or bring up the menu image of the product to match the focus adjustment.

Focus the dial

Thank you for your purchase!

We are committed to providing you with a high-quality product and exceptional customer service. Please scan the below barcode to register your product immediately.

This product comes with 1-year offsite manufacturer warranty.

How to get Warranty

- Scan the above code to get to the nearest service center.
- If you cannot locate one, call us on below numbers or send the product to our central service center by raising a service ticket by scanning the above code.

For any questions or concerns, please do not hesitate to reach out to our customer service team. We are here to help!

Phone: +91-70651-79993/4/5
Email: support@egate-world.com
Website: www.egate-world.com

Thank you for choosing Egate. We appreciate your business and strive to ensure complete peace of mind.

E. & O. E. - Any matter or legal dispute will be entertained in the jurisdiction of Madras Court only.