

E GATE®
USER MANUAL



Content

PACKING LIST	02
NOTICE	02
FUNCTION OVERVIEW	03
REMOTE CONTROL.....	04
QUICK START	05
PROJECTION DISTANCE & SIZE	06
PROJECTION MODE	06
INPUT SOURCE.....	07
BLUETOOTH SETTING	08
PROJECTION	09
WIFI CONNECTION & SCREEN MIRRORING.....	10
PRODUCT SPECIFICATIONS	13

PACKING LIST



Projector



Remote Control



User Manual



AC Cable



Cleaning Cloth



Warranty Card



NOTICE




Not Recommended



FUNCTION OVERVIEW



REMOTE CONTROL




BATTERIES STATEMENT AND NOTICES

Remove the battery compartment cover on the back of your remote by carefully sliding to open. The battery cover can then be lifted away. Fit the correct batteries, referring to the polarity markings. Finally, replace the cover.


NOTE:

- When you receive the product and find that the batteries of the remote control is swollen or softened, please do not use it before you change it.
- Batteries shall not be exposed to excessive heat such as sunshine, fire.
- Make sure that the batteries are installed polarity correctly.
- Only same or equivalent type batteries as recommend are to be used.
- Do not dispose of batteries in fire, battery may explode or leak. Do not try to recharge a battery.
- Do not mix old and new batteries.
- Do not mix alkaline, standard(carbon-zinc), or rechargeable (ni-cad,ni-mh,etc) batteries.


QUICK START



① Plug the power cord into an outlet




② Install batteries in the remote control



③ Turn on
Press the power button on remote or on/off button on unit to turn on the projector



④ Back "home" interface,
Select the page you want to enter



⑤ Turn off
Press the power button and choose "Yes" to turn off the projector


Tips:

1. To prolong the lifespan of the projector, we highly recommended unplug the power cable completely after each use, especially during a long time of no use.
2. After the projector is plugged into the power supply, it takes 10 seconds for the system to detect power on, so please wait for 10 seconds before pressing power to turn it on.
3. The bottom of the machine is the air inlet, please do not place the machine on items such as towels.

PROJECTION DISTANCE & SIZE

The recommended projection screen is around 100-120 inches with a distance of around 1.11-3.32m.

To improve the clarity of your projected images, it is recommended to create ambient darkness and use a high-quality project screen. These factors work together to provide a visually stunning and immersive viewing experience.



PROJECTION MODE

If you want to hang the projector to the ceiling, a projector mount will be needed.

If you want to project in different way, please select corresponding mode in the setting page.




FRONT TABLE



FRONT CEILING



REAR TABLE





REAR CEILING



INPUT SOURCE

Press  on the remote to enter the interface of the Input Source.

A. HDMI Connection




B. USB Connection



BLUETOOTH SETTING

A. Bluetooth Setting

1. Go to Settings > Bluetooth Settings
2. Turn the Bluetooth Connection on and search for nearby Bluetooth devices.
3. Choose correct Bluetooth device to connect.




NOTE:

1. Due to compatibility issues with the Bluetooth protocol, some brands of Bluetooth speakers may not support connection to our projectors. If you have such an issue, feel free to let us know.
2. If you want to connect your headphone/ speaker to an audio port, please disconnect the Bluetooth audio device from the projector first.

PROJECTION


A. Scaling

1. Go to Setting > Projection
2. Press [^] and [v] to adjust the screen size. Press [MENU] to reset settings.



B. Manual Keystone

1. Go to Setting > Projection
2. Select the calibration you prefer.



WiFi CONNECTION & SCREEN MIRRORING

NETWORK

1. Go to Homepage > Settings > Network
2. Turn the WiFi ON and search the WiFi list by "Add WiFi"
3. Select your WiFi then enter password to connect




NOTE:

If you need screen mirroring, the speed of your home network is directly related to the smoothness of video play. Please make sure that the network is good to have a smoother playback.

SCREEN MIRRORING

IOS CAST (For IOS System)


- 1.Go to Homepage > Screen Mirroring > IOS Cast to show the below page
- 2.On your iOS open control center and tap Screen Mirroring
- 3.Looking for device that can mirrored on
- 4.Select EO9026-xxxx from the list to connect



NOTE: Please make sure the projector and your iOS device are connected to the same Wi-Fi. If there is no Wi-Fi, please open a hotspot on your iOS device and connect the projector to it.

Android CAST (For Android System)

1. Go to Homepage > Screen Mirroring > Android Cast to show the below page
2. On your Android device launch the Multi-screen / Wireless Display / Screen Mirroring / Smart View Function.
3. Looking for the device that can be mirrored on
4. Select EO9026-xxxx from the list to connect



NOTE:

1. Please remember to open the Wi-Fi function on your Android device. But not necessary to connect to any Wi-Fi router.
2. When you If there is no Wi-Fi, please open a hotspot on your iOS device and connect the projector to it.

WARRANTY CERTIFICATE **E GATE**[®]

The manufacturer warrants this product to be free from defects in material and manufacturer's workmanship for a period of **1 year** from the date of purchase. This warranty is subject to proper installation and usage as it is intended to be and as mentioned on the Egate's website. The manufacturer will not be liable for any special, incidental or consequential damages in any way related to, or arising out of, defects in, or damage to the unit. Kindly visit our website www.egate-world.com to locate your nearest service center in case of any service issues.

Name : Tel : Model :

Pur.Date : Inv.No. : S.No. :



Scan to Register

This Certificate is valid only after mandatory warranty registration within 15 days of purchase



For Support : call at 706 517 9993 /4 / 5 or mail at support@egate-world.com

**For warranty policy please visit company website www.egate-world.com*

E&OE : Any matter or legal dispute will be entertained in the jurisdiction of Gautam Budh Nagar Court only.



The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Thank you for your purchase!

We are committed to providing you with a high-quality product and exceptional customer service.

Please scan the below barcode to register your product immediately.



**This product comes with 1-year offsite
manufacturer warranty.**

How to get Warranty

In case of warranty/service issue please contact our central service center by raising a service ticket by scanning the above code.

For any questions or concerns, please do not hesitate to reach out to our customer service team. We are here to help!

Phone: +91-70651-79993/4/5

Email: support@egate-world.com

Website: www.egate-world.com

Thank you for choosing Egate. We appreciate your business and strive to ensure complete peace of mind.