E GATE®

USER MANUAL

Content

PACKING LIST 02

NOTICE 02

FUNCTION OVERVIEW 03

REMOTE CONTROL 04

QUICK START 05

INPUT SOURCE 06

A. HDMI CONNECTION 06

B. USB CONNECTION 06

BLUETOOTH SETTING 07

A. BLUETOOTH SETTING 07

B. AS A BLUETOOTH SPEAKER 07

PROJECTION SETTINGS 08

A. AUTO FOCUS 08

B. MANUAL FOCUS 09

C. SCALING 09

WIFI CONNECTION & SCREEN MIRRORING 10

WIFI CONNECTION 10

IOS CAST(FOR IOS SYSTEM) 11

MIRACAST(FOR ANDROID SYSTEM) 12

PACKING LIST

Projector

Remote Control

User Manual

AC Cable



Cleaning Cloth

Warranty Card

NOTICE



FUNCTION OVERVIEW





REMOTE CONTROL





BATTERIES STATEMENT AND NOTICES

Remove the battery compartment cover on the back of your remote by carefully sliding to open. The battery cover can then be lifted away. Fit the correct batteries, referring to the polarity markings. Finally, replace the cover.

NOTE:

- When you receive the product and find that the batteries of the remote control is swollen or softened, please do not use it before you change it.
- Batteries shall not be exposed to excessive heat such as sunshine, fire.
- Make sure that the batteries are installed polarity correctly.
- Only same or equivalent type batteries as recommend are to be used.
- Do not dispose of batteries in fire, battery may explode or leak. Do not try to recharge a battery.
- Do not mix old and new batteries.
- Do not mix alkaline, standard(carbon-zinc), or rechargeable (ni-cad,ni-mh,etc) batteries.

QUICK START



①Plug the power cord into an outlet



② Install batteries in the remote control



③ Turn on

Press the power button on remote or on/off button on unit to turn on the projector



④ Automatic focusing adopts TOF technology, providing a seamless focus and better user experience.

⑤ Back "home" interface, select the video platform you wanto log in



⑥Turn off

Press the power button and choose "**Yes**" to turn off the projector

Tips:

1. To prolong the lifespan of the projector, we highly recommended unplug the power cable completely after each use, especially during a long time of no use.
2. After the projector is plugged into the power supply, it takes 10 seconds for the system to detect power on, so please wait for 10 seconds before pressing power to turn it on.
3. The bottom of the machine is the air inlet, please do not place the machine on items such as towels.

INPUT SOURCE

Press ⏎ on the remote to enter the interface of the Input Source.

A. HDMI Connection





B. USB Connection



Note: When the USB port is connected to a mouse, TV stick or other low power devices, do not connect the power supply to avoid damaging the product!

BLUETOOTH SETTING

A. Bluetooth Setting

1. Go to **Settings > Settings > Bluetooth Setting**
2. Turn the Bluetooth Connection on and search for nearby Bluetooth devices.
3. Choose correct Bluetooth device to connect.



B. As A Bluetooth Speaker

1. Go to **APPS > BluetoothSpeaker**
2. The projector can be used as a Bluetooth speaker.



NOTE:

1. Due to compatibility issues with the Bluetooth protocol, some brands of Bluetooth speakers may not support connection to our projectors. If you have such an issue, feel free to let us know.
2. If you want to connect your headphone/ speaker to an audio port, please disconnect the Bluetooth audio device from the projector first.

PROJECTION SETTINGS

A. Auto Focus

By default, the auto focus mode of the projector is enabled, allowing it to quickly detect and adjust to the optimal clarity of the screen when it is turned on.



NOTE:

① Go to **Settings > Settings > Projection** , you can turn off/on the auto focus function.

② Even after the projector has completed its autofocus, you can still manually focus to refine the picture clarity to your preferences. This gives you complete control over the image quality, ensuring that it meets your exact standards.

B. Manual Focus

You can press the **F−** or **F+** buttons on the remote or go to **Settings > Settings > Projection > Manual Focus** to sharpen the image focus until the blurry image becomes clear.

C. Scaling

1. Go to **Settings > Settings > Projection**
2. Choose **Scaling**
3. Press **Down button** ∨ to Zoom out (100%-50%) and **Up button** ∧ to Zoom in(50%-100%).



WIFI CONNECTION & SCREEN MIRRORING

WIFI CONNECTION

1. Go to **Settings > Settings > Network**
2. Turn the WIFI **ON** and search the WIFI list by "Add WIFI"
3. Select your WIFI then enter password to connect



NOTE:

If you need screen mirroring, the speed of your home network is directly related to the smoothness of video play. Please make sure that the network is good to have a smoother playback.

SCREEN MIRRORING

IOS CAST (For IOS System)

1. Go to **APPS > iOSCast**
2. On your iOS open control center and tap Screen Mirroring
3. Looking for device that can mirrored on
4. Select **EO9022-xxxx** from the list to connect





NOTE: Please make sure the projector and your iOS device are connected to the same Wi-Fi.
If there is no Wi-Fi, please open a hotspot on your iOS device and connect the projector to it.

Miracast(For Android System)

1.Go to **APPS > Miracast**

2.On your Android device launch the Multi-screen/Wireless Display/Screen Mirroring/ Smart View Function.

3.Looking for the device that can be mirrored on

4.Select **EO9022-xxxx** from the list to connect



NOTE:

1.Please remember to open the Wi-Fi function on your Android device. But not necessary to connect to any Wi-Fi router.

2.When you If there is no Wi-Fi, please open a hotspot on your iOS device and connect the projector to it.

WARRANTY CERTIFICATE

E GATE®

The manufacturer warrants this product to be free from defects in material and manufacturer's workmanship for a period of **1 year** from the date of purchase. This warranty is subject to proper installation and usage as it is intended to be and as mentioned on the Egate's website. The manufacturer will not be liable for any special, incidental or consequential damages in any way related to, or arising out of, defects in, or damage to the unit. Kindly visit our website www.egate-world.com to locate your nearest service center in case of any service issues.

Name : ..... Tel : ..... Model : .....

Pur.Date : ..... Inv.No. : ..... S.No. :.....

Scan to Register

This Certificate is valid only after mandatory warranty registration within 15 days of purchase

For Support : call at 706 517 9993 /4 / 5 or mail at support@egate-world.com

**For warranty policy please visit company website www.egate-world.com*

E&OE : Any matter or legal dispute will be entertained in the jurisdiction of Gautam Budh Nagar Court only.

HDMI®
HIGH-DEFINITION MULTIMEDIA INTERFACE

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Thank you for your purchase!

We are committed to providing you with a high-quality product and exceptional customer service.

Please scan the below barcode to register your product immediately.

This product comes with 1-year offsite manufacturer warranty.

How to get Warranty

In case of warranty/service issue please contact our central service center by raising a service ticket by scanning the above code.

For any questions or concerns, please do not hesitate to reach out to our customer service team. We are here to help!

Phone: +91-70651-79993/4/5
Email: support@egate-world.com
Website: www.egate-world.com

Thank you for choosing Egate. We appreciate your business and strive to ensure complete peace of mind.

E. & O.E. : Any matter or legal dispute will be entertained in the jurisdiction of Gautam Budh Nagar Court only.